


# BKFS Thermal Flow Sensor





## OVERVIEW

BKFS series electronic thermal flow switch, based on the thermal principle, enclosed in a closed probe contains two resistors, one of which is heated as the sense resistor and the other is not heated as the base quasi-resistance, when the medium flows, the heat on the heating resistor is taken away, and the resistance value is changed.

Two resistance differences are used as a basis for determining the flow rate. The probe is antifouling coating and can be effective, it prevents the dirt, rust and other dirt in the pipeline from adhering, has stronger anti-pollution ability and is more stable in work.

Bass Ölçme Enstrür Esenşehir Mah. Füsun So +90 216 660 01 63-64







## APPLICATION

Primarily suitable for pneumatic and hydraulic systems, it can be used for shut-off monitoring of circulating water, cutting fluids and lubricating oils, as well as idling protection of pumps.

### SPECIFICATION

The unique tapered probe design prevents the entanglement of the winding in the media. Full waterproof case body design, unique waterproof adjustment knob, can be adjusted without disassembling the sealing screw, it is more reliable.

Applicable to a wide range of pipe diameters, free to adjust the set point, optional anti-corrosion type, withstand voltage up to 100Bar, the indicator light directly shows the flow, optional relay, analog output or analog, switch output integrated output. BKFS series electronic thermal flow switch can monitor the liquid flow in the pipeline in real time, no moving parts, maintenance-free, easy to install, one model is used for a variety of pipe diameter requirements, provide switching output, and adopt 6 The LED display the fluid

flow rate status in real time, enabling the following monitoring functions: media flow, reduced/ increased flow rate; media presence/absence; media flow/stationary; monitoring fluid flow rate within the pipe, shut-off monitoring or preventing pump idling. It is widely used in petrochemical, electric power, metallurgy, steel mills, paper making, food processing, water treatment, battery factories and other industries. Gas-liquid dual-purpose, for pneumatic and hydraulic systems, for shut-off monitoring of circulating water, cutting fluids and lubricants, and idling protection of pumps.






# ■ TECHNICAL DATA


	1150cm/s (water)				
Setup range	3300cm/s (oil)				
	202000 (air)				
Signal output	NPN				
	PNP				
	Relay				
	Analog (420mA)				
	Normally open + normally closed (SPDT)				
Power supply	24V ± 20% DC				
Power	Max. 400mA (PNP or NPN type) up to 1A@48VAC/DC (relay type)				
No-load current	Up to 80mA				
Flow indication	LED				
Setting method	Potentiometer setup				
With stand voltage range	100bar				
Medium temperature change	≤4°C/s				
Response time	113s, typical value 2s				
Initialization time	About 8s				
Electrical protection	Reverse phase				
	Short circuit				
	Overload protection				
Protection class	lp67				
Medium temperature	-20+100°C				
Ambient temperature	-20+80°C				
Storage temperature	-20+100°C				
Wiring method	M12 connector				
Repeatability	±2%				
Material of Probe	Stainless steel housing				
	-				





## DIMENSION













## ELECTRICAL WIRING


#### Relay type output wiring




#### PNP type output wiring



#### NPN type output wiring



#### 4...20mA type output wiring




#### Note:

According to the wiring diagram, the wiring is correctly connected. When the probe touches the medium, when the probe touches the medium, the indicator light is observed. If the red light is on, it can be adjusted counterclockwise. Only the timing adjustment can be made. If the green light is on, it can only be adjusted counterclockwise. Cannot adjust clockwise.






## ■ LED FUNCTION AND SETTING (ANALOG TYPE)



Install the flow switch so that the medium flows at the flow rate that needs to be monitored, and adjust the potentiometer so that the first green LED just turns on. After that, when the flow rate is lower than the current value, the switch is released. To make the switch point smaller than the current flow rate, adjust the potentiometer to make the green LED brighter.

The analog output type flow sensor, the output is 4...20mA, which is proportional to the flow rate, and the output is non-linear. Each sensor has two knobs, one is "upper limit (20mA)" and the other is "lower limit (4mA)" for output setting.



Install the flow sensor to make the medium flow at the lower limit flow rate that needs to be monitored, adjust the lower limit knob to make the first green LED light (4mA); make the medium flow at the upper limit flow rate that needs to be monitored, adjust the upper limit knob to make the fifth The green LED is on (20mA); after that, Output will be proportional to the flow rate between the upper limit and the lower limit, that is, 4mA corresponds to the lower limit flow rate, and 20mA corresponds to the upper limit flow rate.










## ■ CAUTIONS FOR INSTALLATION



When installed vertically, the flow should be flows from bottom to top in the pipe section

1. Horizontal Installation  This installation method can be used when the medium in the pipeline is full. However, when the liquid in the pipeline is not full, this installation method cannot be used because the probe of the flow switch may not be in contact with the medium and cannot work normally.	
Side Installation     This installation method can be used when the medium in the pipeline is full or not full.	
3. Vertical Installation When installed in a vertical pipe, it should be installed under the flow pipe section from bottom to top.	
4. Flip Installation This installation method is forbidden. This installation method will cover the head at the bottom of the pipe, causing the flow switch to not work properly. If the sealing is not tight during installation, the leakage water will be soaked for a long time, causing the flow switch to be damaged, and this installation method is not conducive to setting the parameters of the flow switch.	









# ORDERING

Model						BKFS
Power Supply	DC					24V DC
	AC					230V AC
		Р				PNP output
Output		Ν				NPN output
		R				Relay output
		А				420 mA Output
Probe Length			15			15 mm
			25			25 mm
Process Connection		015		G 1/2"		
				025		G 1"
Enclosure / Hazardouse area			NN	IP 67		
				Ex D	Ex d IIC T6 Gb	
				Ex ia	Ex ia II C T6	



